


# Reliable ELD Inspection Mode



- ✓ Tap 'Reports' in the menu and select Inspect logs. This allows an officer to directly view your logs from your mobile device.
- ✓ The inspector can use the arrows to navigate to previous or next day's logs.
- ✓ To exit inspection mode, tap the back arrow in the top left corner of the app.

## Send Logs

RELIABLE ELD can produce and transfer ELD records via telematics, including: wireless web services.

To send ELD records via web services, tap 'Reports' and then select 'Send Logs' and then select 'Web-service', and press 'Send Logs'

To send ELD records via email, tap 'Reports,' select 'Email Logs,' enter the email provided by an authorized safety official, and press 'Save.'

[www.reliableeld.com](http://www.reliableeld.com)

Contact the support team at [info@reliableeld.com](mailto:info@reliableeld.com)

# Reliable ELD

## Malfunction Manual



### ✓ Malfunction Indication

Contact support immediately if the LED light on the device is off while plugged into the diagnostic port or if the app reports a malfunction

### ✓ Note the Malfunction

Document the malfunction and send a written notice to your fleet within 24 hours.

### ✓ Switch to Paper Logs

Maintain a paper log for the current day and continue until the device is repaired or replaced. If inspected, present the past 7 days of records from the app.

### ✓ 8 Days Rule

In case of an ELD malfunction, the motor carrier must resolve the issue within 8 days of its discovery